

## CHIRP - Bug # 2711

|                        |   |                  |        |
|------------------------|---|------------------|--------|
| <b>Status:</b>         | Closed  | <b>Priority:</b> | Normal |
| <b>Author:</b>         | Robert Duhs   | <b>Category:</b> |        |
| <b>Created:</b>        | 07/08/2015  | <b>Assignee:</b> |        |
| <b>Updated:</b>        | 02/12/2017  | <b>Due date:</b> |        |
| <b>Chirp Version:</b>  | 0.4.0   |                  |        |
| <b>Model affected:</b> | uv-5rv2+  |                  |        |
| <b>Platform:</b>       | MacOS   |                  |        |
| <b>Subject:</b>        | Hello i am new and i need alot of help (mac user)   |                  |        |
| <b>Description</b>     | <p>i am new and i just want to program my radio. i am having trouble wit it all. i have downloaded chirp and the python package. and i cant see to find my usb cable in my drive to download all my channels, program names to channels and to welcome message. i need a 101 how to intro help. it wants me to clone my radio with a bluetooth driver and i dont know what to do. please help i have download chirp, its python that it needs and a FDTI driver software. i also am using a baofeng usb connection.</p> <p>thank you</p> <p>Lee</p> |                  |        |

### History

#1 - 12/30/2015 12:24 pm - Tyler Tidman

Did you try looking at the documentation found at <http://chirp.danplanet.com/projects/chirp/wiki/Documentation> yet?

#2 - 02/12/2017 05:23 pm - Tim Smith

- Status changed from New to Closed