

## CHIRP - Bug # 4841

<b>Status:</b>	Closed	<b>Priority:</b>	Normal
<b>Author:</b>	Manuel Ziegler	<b>Category:</b>	
<b>Created:</b>	05/25/2017	<b>Assignee:</b>	
<b>Updated:</b>	03/13/2020	<b>Due date:</b>	
<b>Chirp Version:</b>	daily		
<b>Model affected:</b>	Yaesu VX-8DR		
<b>Platform:</b>	MacOS		
<b>Subject:</b>	Yaesu VX 8DR		
<b>Description</b>			
<p>I am using Mac OS 10.12.05 and programming a Yaesu VX 8DR. When programming I am not able to select NFM under Mode, just FM, AM and WFM even though the radio can pick up NFM. Anyone have an idea how to active the NFM selection in Mode.</p>			

### History

#### #1 - 03/13/2020 06:18 pm - Bernhard Hailer

- Status changed from New to Closed
- Target version set to chirp-daily
- Model affected changed from (All models) to Yaesu VX-8DR

This has been added a short while ago. Use a (very) recent version of Chirp.