

CHIRP - Bug # 4135

Status:	Closed	Priority:	Normal
Author:	Ed Morales	Category:	
Created:	10/15/2016	Assignee:	
Updated:	02/25/2020	Due date:	
Chirp Version:	daily		
Model affected:	(All models)		
Platform:	Windows		
Subject:	I cannot get CHIRP to work on my newer Windows Laptop		
Description	I run Windows 8.1. Please help me.		

History

#1 - 10/16/2016 01:04 pm - Jim Unroe

- Status changed from New to Feedback

We need more details. Are there any error messages? Have you disabled "Smartscreen"?

Jim

#2 - 10/16/2016 05:16 pm - Ed Morales

Jim Unroe wrote:

We need more details. Are there any error messages? Have you disabled "Smartscreen"?

Jim

Error says it could not open port com 2. I don't know what you mean by smart screen. It also will not let me change the port com #.

#3 - 10/16/2016 08:40 pm - Ryan Tourge

The version you are using is several years old. You should try the latest daily build.

#4 - 10/16/2016 08:42 pm - Ed Morales

Ryan Tourge wrote:

The version you are using is several years old. You should try the latest daily build.

I downloaded the latest version and it still does not work.

#5 - 10/17/2016 09:40 am - Jim Unroe

Ed Morales wrote:

Jim Unroe wrote:

We need more details. Are there any error messages? Have you disabled "Smartscreen"?

Jim

Error says it could not open port com 2. I don't know what you mean by smart screen. It also will not let me change the port com #.

This error appears to indicate that you are either accessing the wrong com port or a device driver that is compatible with the chip in the programming cable has not been installed (common problem with Windows and Prolific type chips).

Most Prolific type chips are unauthorized copies (counterfeit) and the device driver that is automatically installed is (intentionally) incompatible with these chips. You must download, install and select an older but compatible device driver.

See the [Cables & Drivers](#) page on the Miklor website.

Jim

#6 - 02/25/2020 03:42 pm - Bernhard Hailer

- Status changed from *Feedback* to *Closed*
- Priority changed from *High* to *Normal*
- Target version set to *chirp-daily*
- Chirp Version changed from *0.4.0* to *daily*

No more traffic on this ticket.